



NATUZZI


Teatro




Vers. 060/155




Vers. 146/446




Vers. 630/693




Vers. 030/193




Vers. 348/368




Vers. 004/154




**Vers. LAF 047
Vers. RAF 049**




Vers. 291




344 SECT.450+338+076+291X2+049




345 SECT.400+352+076+001+402




Vers. 001




Vers. 076




**Vers. LAF 360/450
Vers. RAF 362**




**Vers. LAF 098/400
Vers. RAF 099**




Vers. 328/338




Vers. 351/352




Vers. 275



Vers. 307



Vers. 010



Vers. 010

This information is based on the latest product information available at the time of printing. The right to discontinue and make changes is reserved.

The sectional and motion pieces are shown as left hand.